

*mob*ilator<sup>TM</sup>.pl

## QUICK GUIDE

# MS-B03 Wireless Barcode Scanner

### I. Standard Package

1. a handheld scanner;
2. a wireless receiver;
3. a 5v AC/DC power adapter (use only for charging the battery);
4. a user manual.

### II. Safety Cautions

Please read the following concise rules. Violation of these rules may result in hazard or infringement of the law. This guide contains more detailed information on safety alerts.



**Power-on:** Please do not turn on the device when wireless device is prohibited or its operation may cause interference or hazard.



**Interference:** Wireless devices are apt to be disturbed and adversely affect the performance.



**Rational use:** Use the device in the ways described in this guide only.



**Maintenance:** Only qualified service personnel can assemble or fix the device.



**Attachments and Battery:** Use only the authorized attachments and battery. Do not connect to inconsistent products.



**Water-proofing:** It is not a waterproof device. Please keep it dry.




**Connection to devices:** In need of connecting to other devices, please look through its manual or consult the manufacturer to get enough safety information. Do not connect to inconsistent devices.

### III. Wireless Communication

Working frequency is the universal 2.400-2.483MHz ISM band. Each receiver corresponds to one handheld scanner. In open ground with absence of obstructions, the effective transmission distance between handheld scanner and receiver is 10 meters.

## IV. Scanner Outside View:



### ① LED Lamp:

In sleeping mode, the lamp is on and red;  
 In working mode, the lamp flickers once for reading a barcode;  
 The lamp is in green when the battery is on charge;

### ② Scan Window:

Resin filter with dust and scratch-proof design;  
 In working mode, one press on the trigger initiates a light beam.

### ③ Trigger Button:

To power on the scanner, hold the trigger for 4 seconds and release when a beep tone sounds;  
 When working, one press initiates one scan;  
 To shut down the scanner, hold the trigger for 6 seconds and release when a beep tone sounds;  
 Do not press the trigger button by force.

### ④ Buzzer:

Hold the trigger button for 4 seconds and the buzzer makes a beep to indicate

the success of power-on;

When working, the buzzer makes a beep for each successful reading of a barcode;

A successful sending of a data record also activates a beep sound.

Hold the trigger button for 6 seconds and the buzzer makes a beep to indicate the success of shutting down;

⑤ **Standby Battery Bolt:**

Design for further fastening battery;

The scanner base itself can fasten the battery quite well, so the bolt is not mounted until necessary;

If the bolt is mounted, it must be unbolted when replacing a battery.

⑥ **Charging Port:**

Accepts the plug of the 5V AC/DC power adapter (use only for charging the battery);

Please use the manufacturer authorized power adapter for battery charging only, or it may cause damage.

⑦ **Mini USB Receiver**

Connect to the data terminal (eg. computer) directly or through an USB extension cable. It's recommended to use an extension cable for better reception and protection.

⑧ **Receiver Code**

Used to identify the bonding relationship between scanner and receiver.

## V. Battery Charging



- ① The charging port on the handheld scanner can be only used for battery charging. Do not connect to other cables.
- ② The LED lamp on the scanner lights up green on charging and turns out when battery is full.
- ③ Charging time is approximately 4 hours.

## VI. Operation Instructions

- 1. Connect the receiver to the data terminal (eg. Computer).
- 2. Turn on the scanner: press the trigger for 4 seconds and release when the buzzer makes a beep.

- 3. Read the “RESET” barcode to initialize the scanner.



- 4. Read the “RS232” barcode.



### NOTES:

- \* If the scanner is not in use for 10 minutes, it will shutoff automatically.
- \* Scanner and receiver have been well paired. Unless necessary, please don't pair again.

In case there is a must to re-pair them, please scan first the "RS232" barcode, then within 5 seconds scan the "PAIR" barcode. The re-pairing is successful if two beeps sounded.



PAIR

## VII. Trouble Shooting

- ① **Problem:** The scanner is humming or beeping.  
**Cause:** Battery is running low.  
**Solution:** Recharge the battery.
- ② **Problem:** The scanner squeals and emits no laser beam.  
**Cause:** The scanner is not connected to the data terminal (Computer) or is out of range.  
**Solution:** Please insert the receiver in the data terminal (Computer) or move nearer to the data terminal.
- ③ **Problem:** The scanner works normally but no data displays on the data terminal (computer).  
**Cause:** The interface setting is not correct.  
**Solution:** Please refer to V. Operation Instruction in this manual for a correct setting.
- ④ **Question:** Can the charging port be used to transfer data?  
**Answer:** No. It is only used for charging the battery
- ⑤ **Question:** May the radio signal disturb electrical household appliances (eg. TV)?  
**Answer:** In general, the wireless laser scanner use low-power signals below 10dbm and 433MHZ frequency and won't interfere with other radio signals.

APPENDIX

OPTION SETUP

UPC/EAN

EXPAND UPC-E TO UPC-A - ENABLE



EXPAND UPC-E TO UPC-A - DISABLE



EXPAND UPC-E TO EAN-13 - ENABLE



EXPAND UPC-E TO EAN-13 - DISABLE



CONVERT EAN-13 TO ISBN - ENABLE



CONVERT EAN-13 TO ISBN - DISABLE



UPC/EAN SUPPLEMENTS - DISABLE



UPC/EAN SUPPLEMENTS - 2 DIGIT ONLY



UPC/EAN SUPPLEMENTS - 5 DIGIT ONLY



UPC/EAN SUPPLEMENTS - 2 & 5 DIGIT



UPC/EAN REDUNDANCY - ENABLE



UPC/EAN REDUNDANCY - DISABLE



COMMON SETUP

STRIP 1 LEADING CHARACTER ON ALL BAR CODES THAT START WITH '12345'



OFF



STRIP 1 TRAILING CHARACTER



OFF



FILTER LEADING SPACES



OFF



FILTER TRAILING SPACES



OFF



FILTER ALL ' \_ ' CHARACTERS



DISABLE FILTER ALL ' \_ ' CHARACTERS



INSERT LEADING ZERO



DISABLE INSERT LEADING ZERO



TERMINATION STRING SETUP

TERMINATION CHAR - CR



TERMINATION CHAR - LF



TERMINATION CHAR - CR+LF



DISABLED



CODE128 TERMINATION CHAR - CR



CODE128 TERMINATION CHAR - LF



CODE128 TERMINATION CHAR - CR+LF



CODE128 TERMINATION CHAR - REMOVED



CODE39 TERMINATION CHAR - TAB



CODE39 TERMINATION CHAR - TAB - REMOVED



PREAMBLE - STX



POSTAMBLE - ETX



