

BIOS Update for HTC Shift (Version V1.0.0.8)

BIOS Installation Guide

The BIOS Update enhances USB flash disk compatibility on the HTC Shift mobile computer.

To determine which installer you should use to update the BIOS, check first the type of keyboard on your mobile computer:

- For HTC Shift mobile computers that use the UK keyboard, use the **080522UK.ROM** installer to upgrade your BIOS and EC firmware.




- For HTC Shift mobile computers that use other types of keyboards, use the **080522.ROM** installer to upgrade your BIOS and EC firmware.



Warning: Please be sure to use the correct BIOS update installer for your device. Otherwise, the keyboard keys will be mapped incorrectly and you will not get the correct characters when you type on the keyboard.

Updating the BIOS

1. After downloading the BIOS update installer to your mobile computer, unzip the installer and then run **htcflash.exe**.
2. When you see the HTC Firmware Update Utility window, click **Open**.
3. Select the appropriate installer (*.ROM) file to use. Double-click the file to run the installer.



-
- The screenshot displays the HTC Firmware Update Utility V1.0.0.8 application window. The utility provides details about the system's BIOS and EC versions, as well as the ROM files being used for the update. The 'Update' button is prominently marked with a red box and the number 4, indicating the next step in the process. In the background, a Windows Explorer window shows the '080522BIOSEC' folder containing the 'htcflash' file, which is the target of the update utility.