





# TT35A RFID\_LF UserManual



TT35A

| 日期           | 内容       | 修改人 |
|--------------|----------|-----|
| 2014. 07. 28 | 使用新模板写文档 | 刁显华 |
| 2014. 08. 21 | 整理英文文档   | 刁显华 |
|              |          |     |
|              |          |     |
|              |          |     |
|              |          |     |
|              |          |     |

1. Enter menu click **LFRFID** to open the demo, as below.



2. Identify 125KHz card. Click **OFF** to turn it to **ON** , When the card into the search range will show the corresponding number on the screen. You need click **Clear** to show numbers when card number full screen. Press **return key** or click **Close App** button to exit demo.



3. Identify 134.2KHz card. Same as 125KHz card.

